

PRODUCT USER GUIDE

DCBP-400-60-6 Rack Mount DC Distribution Panel

Owners Guide

(These instructions are intended for use by a technician familiar with electronic products)

- 19" rack DC distribution panel
- 400 Amps maximum
- DC Breakers rated up to 150 VDC
- 6 Breakers @ 60 Amps
- 3 year warranty



DESCRIPTION

The DCBP-400-60-6 is a commercial duty rack mount distribution panel with six 60 amp direct current breakers installed. NOTE: This product is intended for use with DuraComm DCBB-700 Bus Bar or similar product.

SPECIFICATIONS

Operational DC Voltage	150 VDC Max
Maximum Current, continuous	400 Amps
Input Voltage Range	
Working Temperature range	40 F to +158 F (-40 C to +70 C)
Storage Temperature	40 F to + 185 F (-40 C to +85 C)
Size	3.5"H x 19"W x 10.5"D (88.9mm H x 483mm W x 267mm D)
Breakers	MidNite Solar 60A/150 VDC
Weight	11 lbs

INSTALLATION WARNING

The individual user should take care to determine, prior to use or installation, whether this device is suitable, adequate or safe for the use intended. Since individual applications are subject to great variation, DuraComm makes no representation or warranty as to the merchantability, suitability or fitness of these units for any specific application.

DO NOT block any of the cooling vents on the sides and always allow adequate ventilation by not installing the unit inside tightly closed spaces. Physical mounting position is not critical but the cooling vents must not be blocked.

THERE ARE NO USER SERVICEABLE PARTS INSIDE. SERVICE AND REPAIR MUST BE REFERRED TO QUALIFIED FACTORY PERSONNEL

1 of 3 September 17, 2014


RECOMMENDED COPPER WIRE SIZE FOR CURRENT CAPACITY

All kinds of copper conductors can be clamped without treatment. DO NOT solder tin stranded conductors. The solder yields and fractures under high pressure. The result is increased contact resistance and excessive temperature rise. Additionally, corrosion has been observed due to the fluxes. Notch fractures at the transition from the rigid tinned part to the flexible conductors are also possible. Ferrules can be used as a protection when wiring stranded conductors. Copper ferrules prevent the current transfer from being influenced by dissimilar metals and remove the risk of corrosion. Always use the correct tool to crimp the ferrule.

(Insulated Wire, Single Conductor in free air)

Current Level in Amperes	Wire Size
<7 AMPERES	20 AWG Up to 5 feet
	18 AWG Up to 10 feet
14 AMPERES	18 AWG Up to 5 feet
	16 AWG Up to 10 feet
20 AMPERES	16 AWG Up to 5 feet
	14 AWG Up to 10 feet
30 AMPERES	14 AWG Up to 5 feet
	12 AWG Up to 10 feet
40 AMPERES	12 AWG Up to 5 feet
	10 AWG Up to 10 feet
50 AMPERES	10 AWG Up to 5 feet
	8 AWG Up to 10 feet
70 AMPERES	8 AWG Up to 5 feet
	6 AWG Up to 10 feet
100 AMPERES	6 AWG Up to 5 feet
	4 AWG Up to 10 feet

DCBP-400-60-6



2 of 3 September 17, 2014

LIMITED WARRANTY

DuraComm warrants to the initial end user, each power supply manufactured by DuraComm to be free from defects in material and workmanship, when in normal use and service for a period of three years from the date of purchase, from an authorized DuraComm dealer.

Should a product manufactured by DuraComm fail or malfunction due to manufacturing defect, or faulty component, DuraComm, at its option, will repair or replace the faulty product or parts thereof, which, after examination by DuraComm, prove to be defective or not operational according to specifications in effect at the time of sale to the initial end user. The product that is replaced or repaired under the provisions of this warranty, will be warranted for the remainder of the original warranty period, only, and will not extend into a new three year warranty period.

The limited warranty does not extend to any DuraComm product which has been subject to misuse, accidental damage, neglect, incorrect wiring not associated with manufacture, improper charging voltages, or any product which has had the serial number removed, altered, defaced, or changed in any way.

DuraComm reserves the right to change, alter, or improve the specifications of its products at any time, and by so doing, incurs no obligation to install or retrofit any such changes or improvements in or on products manufactured prior to inclusion of such changes.

DuraComm requires any product needing in or out of warranty service to be returned to DuraComm. All requests for warranty service must be accompanied by proof of purchase, such as bill of sale with purchase date identified. DuraComm is not responsible for any expenses or payments incurred for the removal of the product from its place of use, transportation or shipping expenses to the place of repair, or return expenses of a repaired or replacement product to its place of use.

The implied warranties which the law imposes on the sale of this product are expressly LIMITED, in duration, to the three (3) year time period specified herein. DuraComm will not be liable for damages, consequential or otherwise, resulting from the use and operation of this product, or from the breach of this LIMITED WARRANTY.

Some states do not allow limitations on the duration of the implied warranty or exclusions or limitations of incidental or consequential damages, so said limitations or exclusions may not apply to you. This warranty gives you specific legal rights which vary from state to state.

This warranty is given in lieu of all other warranties, whether expressed, implied, or by law. All other warranties, including WITHOUT LIMITATION, warranties of merchantability and fitness or suitability for a particular purpose, are specifically excluded. DuraComm reserves the right to change or modify its warranty and service programs without prior notice.

DuraComm® Corporation

6655 Troost Avenue Kansas City, MO 64131 Phone (816) 472-5544 Fax (816) 472-0959 www.duracomm.com

3 of 3 September 17, 2014