

PRODUCT USER GUIDE

EH-48-5N

Indoor/Outdoor Heavy Duty AC to DC Wall Mount Power Supply Owners Guide

(These instructions are intended for use by a technician familiar with electronic products)

- Input Voltage 90 to 264 VAC
- NEMA 4X Enclosure
- Low Voltage Disconnect
- Internal Battery 12v / 7 Amp-hour X 4 (48) Powersonic PS-R1270-F2 or Equivalent
- AC Fail Relay Contacts (DC okay)
- Output with 5 Fuse Distribution Block
- AC Input Breakers (included)
- Maximum Internal working Temperature -25c~+70c
- 3 year warranty



DESCRIPTION

The Environmentally Hardened EH-48-5N is a weatherproof power supply with Low Voltage Disconnect and Batter Back-up, housed in 16-gauge steel NEMA 4X enclosure, and which are dust-proof and moisture-resident.

SPECIFICATIONS

Output Voltage Output Voltage Tolerance	54.7 VDC
Output voitage Tolerance	
Output amperage	3 Amps Continuous, 5 Amps Maximum
Maximum Power, continuous	
Maximum ripple and noise	150 mV p-p max
Input Voltage	90 to 264 VAC
Input frequency range	47-63 Hz
Maximum AC Current	4 A/120 VAC; 2 A/240 VAC
Typical Efficiency	84 pct
Max inrush current, single cycle	35 Amps
Max inrush current, single cycle	Fold back Limiting
Overload Protection (operates)	typical 110-120 pct
Overload Protection (operates)	50 mV
Load Regulation	100 mV (20-100 pct load)
Over Temperature	
Rise Time following ON	50mS
Hold Time following OFF	10 mS
Working Temperature range	-13~ +158F (-25~70C)
Storage Temperature	
Withstand Voltage*	1.3 KV @ 10111a (1/P-U/P, 1/P-FG)/1 MIN
Continued	500 v @ 10 ma (O/P-FG)/1 min
Dimensions	18"H x 16"W x 9"D inches
Weight	41 lbs

BATTERY BACK UP & CHARGER

Auto-revert to battery or power supply	Provided by dual Shottky diode in OR configuration
Maximum output current in battery mode	10 Amps (limited by 10 Amps breaker)
Maximum Charger Voltage	55.2 VDC
Maximum Recharger Rate	2 Amps Float Charger
Visual Indication	.LED indication: Red = AC Fail or Power Supply Fail, Green = DC Output Okay

LOW VOLTAGE DISCONNECT & AC FAIL RELAY

Maximum Interrupt Current / Continuous Current	10 Amps DC
Disconnect Voltage	44 VDC
Reconnect Voltage	50 VDC
Disconnect Delay	
AC Fail Relay	· · · · · · · · · · · · · · · · · · ·

INSTALLATION WARNING

The individual user should take care to determine, prior to use or installation, whether this device is suitable, adequate or safe for the use intended. Since individual applications are subject to great variation, DuraComm makes no representation or warranty as to the merchantability, suitability or fitness of these units for any specific application.

DO NOT block any of the cooling vents on the sides and always allow adequate ventilation by not installing the unit inside tightly closed spaces. Physical mounting position is not critical but the cooling vents must not be blocked. Make certain the input voltage switch is set to the correct voltage BEFORE applying AC power.

CONDUCTOR PRETREATMENT

All kinds of copper conductors can be clamped without treatment. **DO NOT** solder tin stranded conductors. The solder yields and fractures under high pressure. The result is increased contact resistance and excessive temperature rise. Additionally, corrosion has been observed due to the fluxes. Notch fractures at the transition from the rigid tinned part to the flexible conductors are also possible. Ferrules can be used as a protection when wiring stranded conductors. Copper ferrules prevent the current transfer from being influenced by dissimilar metals and remove the risk of corrosion. Always use the correct tool to crimp the ferrule.

RECOMMENDED COPPER WIRE SIZE FOR CURRENT CAPACITY

(Insulated Wire, Single Conductor in free air)

Current Level in Amperes	<u>Wire Size</u>
<7 AMPERES	20 AWG Up to 5 feet
	18 AWG Up to 10 feet
14 AMPERES	18 AWG Up to 5 feet
	16 AWG Up to 10 feet
20 AMPERES	16 AWG Up to 5 feet
	14 AWG Up to 10 feet
30 AMPERES	14 AWG Up to 5 feet
	12 AWG Up to 10 feet
40 AMPERES	12 AWG Up to 5 feet
	10 AWG Up to 10 feet
50 AMPERES	10 AWG Up to 5 feet
	8 AWG Up to 10 feet
70 AMPERES	8 AWG Up to 5 feet
	6 AWG Up to 10 feet
100 AMPERES	6 AWG Up to 5 feet
	4 AWG Up to 10 feet

LIMITED WARRANTY

DuraComm warrants to the initial end user, each power supply manufactured by DuraComm to be free from defects in material and workmanship, when in normal use and service for a period of three year from the date of purchase, from an authorized DuraComm dealer.

Should a product manufactured by DuraComm fail or malfunction due to manufacturing defect, or faulty component, DuraComm, at its option, will repair or replace the faulty product or parts thereof, which, after examination by DuraComm, prove to be defective or not operational according to specifications in effect at the time of sale to the initial end user. The product that is replaced or repaired under the provisions of this warranty, will be warranted for the remainder of the original warranty period, only, and will not extend into a new three year warranty period.

The limited warranty does not extend to any DuraComm product which has been subject to misuse, accidental damage, neglect, incorrect wiring not associated with manufacture, improper charging voltages, or any product which has had the serial number removed, altered, defaced, or changed in any way.

DuraComm reserves the right to change, alter, or improve the specifications of its products at any time, and by so doing, incurs no obligation to install or retrofit any such changes or improvements in or on products manufactured prior to inclusion of such changes.

DuraComm requires any product needing in or out of warranty service to be returned to DuraComm. All requests for warranty service must be accompanied by proof of purchase, such as bill of sale with purchase date identified. DuraComm is not responsible for any expenses or payments incurred for the removal of the product from its place of use, transportation or shipping expenses to the place of repair, or return expenses of a repaired or replacement product to its place of use.

The implied warranties which the law imposes on the sale of this product are expressly LIMITED, in duration, to the three (3) year time period specified herein. DuraComm will not be liable for damages, consequential or otherwise, resulting from the use and operation of this product, or from the breach of this LIMITED WARRANTY.

Some states do not allow limitations on the duration of the implied warranty or exclusions or limitations of incidental or consequential damages, so said limitations or exclusions may not apply to you. This warranty gives you specific legal rights which vary from state to state.

This warranty is given in lieu of all other warranties, whether expressed, implied, or by law. All other warranties, including WITHOUT LIMITATION, warranties of merchantability and fitness or suitability for a particular purpose, are specifically excluded. DuraComm reserves the right to change or modify its warranty and service programs without prior notice.

DuraComm® Corporation

6655 Troost Avenue Kansas City, MO 64131 Phone (816) 472-5544 Fax (816) 472-0959 www.duracomm.com