A Benny Lee Company

# PRODUCT USER GUIDE

### **RLP-5048M**

# 2.4 kW Heavy Duty Rack Mount Power Supply Owners Guide

(These instructions are intended for use by a technician familiar with electronic products)

- High Power 48 VDC Output power supply for 220 VAC only
- 2400 Watts of output power at 80% efficiency
- Short Circuit / Overload / Over Voltage / Over Temperature
  Protection
- Usable in positive or negative ground applications
- RLP-5048M has a meter for volts and a meter for current
- 3 year warranty



#### DESCRIPTION

The RLP-5048M power supply has 2400 watts of output power at 80 percent efficiency. The RLP can operate at -20 C to +60 C with short circuit, overload, over voltage and over temperature protection. This model is usable in positive or negative ground applications. The input voltage for the RLP-5048M models is 220 VAC only. The 2.4kW Heavy Duty Rack Mount Power Supply comes with two meter displays, the far left for voltage and the right for amperage.

### **SPECIFICATIONS**

Output Voltage	48 VDC
Output Voltage Tolerance	
Output Amperage	
Maximum Power,	
Output Voltage Adjustment	
Maximum Ripple and Noise	150 mV p-p max
Input Voltage, Auto Ranging	
Input Frequency Range	
Maximum AC Current	
Typical Efficiency	
Max Inrush Current, single cycle	
Short Circuit Protection	Foldback Limiting
Overload Protection (operates)	typical 110-120 %
Line Regulation	50 mV
Load Regulation	100 mV (20-100 % load)
Fan Control	Heat sink temp >140 F (60 C) = ON
Over Temperature	>195 F (90 C) auto output shutdown
Rise Time following ON	50 mS
Hold Time following OFF	10 mS
Working Temperature Range	
Storage Temperature	
Withstand Voltage*	
(Continued)	<b>-</b> ,
Dimensions	
Weight	

### **METER CIRCUITS**

The panel meter is switched to provide DC output voltage measurement and individual output load current measurement for each individual module.

When set to the VOLT position, the full-scale reading is 100 volts.

When set to the AMP position, the full-scale reading is 100 amps.

The meter and associated circuitry accuracy is 10 percent of full scale deflection. Since full scale is 100 amps, a 20 amp current can vary from 18 to 22 amps indicated. To prevent unnecessary output voltage drops, the meter circuits use the voltage drop of the black #10 AWG negative return to the module as a meter shunt. The #10 AWG wire provides a nominal 100 mV drop at 100 amps

The meter sensitivity for voltage measurement is 1000 ohms per volt.

### **INSTALLATION WARNING**

## <u>WARNING</u>: THERE ARE NO USER SERVICEABLE PARTS INSIDE. SERVICE AND REPAIR MUST BE REFERRED TO QUALIFIED FACTORY PERSONNEL.

**NOTE**: The individual user should take care to determine, prior to use or installation, whether this device is suitable, adequate or safe for the use intended. Since individual applications are subject to great variation, DuraComm makes no representation or warranty as to the merchantability, suitability or fitness of these units for any specific application.

<u>NOTE:</u> The precision regulated power supplies operate internally from voltages in excess of 12/24/48 volts. In rare cases, voltage spikes or transients on the AC power line, or overheating, may cause a component failure in the power supply. Overloading the output will cause the over current feature to operate. In either case, the cause must be determined and corrected. **Failures require investigation as to cause and/or repair of the unit.** 

#### **INSTALLER NOTES**

**NOTE: DO NOT** block any of the cooling vents on the sides and always allow adequate ventilation by not installing the unit inside tightly closed spaces. Physical mounting position is not critical but the cooling vents must not be blocked.

NOTE: The outputs are NOT referenced to the chassis. The Modular System can be used either positive or negative ground.

### **CONDUCTOR PRETREATMENT**

All kinds of copper conductors can be clamped without treatment. DO NOT solder tin stranded conductors. The solder yields and fractures under high pressure. The result is increased contact resistance and excessive temperature rise. Additionally, corrosion has been observed due to the fluxes. Notch fractures at the transition from the rigid tinned part to the flexible conductors are also possible. Ferrules can be used as a protection when wiring stranded conductors. Copper ferrules prevent the current transfer from being influenced by dissimilar metals and remove the risk of corrosion. Always use the correct tool to crimp the ferrule.

### **RECOMMENDED COPPER WIRE SIZE FOR CURRENT CAPACITY**

<u>Current Level in Amperes</u>	<u>Wire Size</u>
<7 AMPERES	20 AWG Up to 5 feet
	18 AWG Up to 10 feet
14 AMPERES	18 AWG Up to 5 feet
	16 AWG Up to 10 feet
20 AMPERES	16 AWG Up to 5 feet
	14 AWG Up to 10 feet
30 AMPERES	14 AWG Up to 5 feet
	12 AWG Up to 10 feet
40 AMPERES	12 AWG Up to 5 feet
	10 AWG Up to 10 feet
50 AMPERES	10 AWG Up to 5 feet
	8 AWG Up to 10 feet
70 AMPERES	8 AWG Up to 5 feet
	6 AWG Up to 10 feet
100 AMPERES	6 AWG Up to 5 feet
	4 AWG Up to 10 feet

(Insulated Wire, Single Conductor in free air)

### LIMITED WARRANTY

DuraComm warrants to the initial end user, each power supply manufactured by DuraComm to be free from defects in material and workmanship, when in normal use and service for a period of three year from the date of purchase, from an authorized DuraComm dealer.

Should a product manufactured by DuraComm fail or malfunction due to manufacturing defect, or faulty component, DuraComm, at its option, will repair or replace the faulty product or parts thereof, which, after examination by DuraComm, prove to be defective or not operational according to specifications in effect at the time of sale to the initial end user. The product that is replaced or repaired under the provisions of this warranty, will be warranted for the remainder of the original warranty period, only, and will not extend into a new three year warranty period.

The limited warranty does not extend to any DuraComm product which has been subject to misuse, accidental damage, neglect, incorrect wiring not associated with manufacture, improper charging voltages, or any product which has had the serial number removed, altered, defaced, or changed in any way.

DuraComm reserves the right to change, alter, or improve the specifications of its products at any time, and by so doing, incurs no obligation to install or retrofit any such changes or improvements in or on products manufactured prior to inclusion of such changes.

DuraComm requires any product needing in or out of warranty service to be returned to DuraComm. All requests for warranty service must be accompanied by proof of purchase, such as bill of sale with purchase date identified. DuraComm is not responsible for any expenses or payments incurred for the removal of the product from its place of use, transportation or shipping expenses to the place of repair, or return expenses of a repaired or replacement product to its place of use.

The implied warranties which the law imposes on the sale of this product are expressly LIMITED, in duration, to the three (3) year time period specified herein. DuraComm will not be liable for damages, consequential or otherwise, resulting from the use and operation of this product, or from the breach of this LIMITED WARRANTY.

Some states do not allow limitations on the duration of the implied warranty or exclusions or limitations of incidental or consequential damages, so said limitations or exclusions may not apply to you. This warranty gives you specific legal rights which vary from state to state.

This warranty is given in lieu of all other warranties, whether expressed, implied, or by law. All other warranties, including WITHOUT LIMITATION, warranties of merchantability and fitness or suitability for a particular purpose, are specifically excluded. DuraComm reserves the right to change or modify its warranty and service programs without prior notice.

### **DuraComm<sup>®</sup> Corporation**

6655 Troost Avenue Kansas City, MO 64131 Phone (816) 472-5544 Fax (816) 472-0959 www.duracomm.com